

**COM-TROL MCS-4000
"HOT KEY" INSTRUCTIONS**

FROM THE "MAIN MENU", PRESS THE SIDE KEY FOR "TASK STATUS", AND PRESS "ENTER".

SELECT THE DESIRED TASK FROM THE LIST WITH THE APPROPRIATE SIDE KEY, AND PRESS "ENTER"

(OTHER SIDE)

PRESS THE FOLLOWING KEYS TO GO TO:

1. SETPOINTS
2. TOD SCHEDULES (IF APPLICABLE)
3. RELAY/DIGITAL OUTPUTS
4. DIGITAL INPUTS
5. ANALOG INPUTS
6. ANALOG OUTPUTS
7. ANALOG INPUT ALARMS
8. DIGITAL INPUT ALARMS
9. CLEARS ANY COMPUTER RELAY OVERRIDES WITHIN THAT TASK

**COM-TROL MCS-4000
"HOT KEY" INSTRUCTIONS**

FROM THE "MAIN MENU", PRESS THE SIDE KEY FOR "TASK STATUS", AND PRESS "ENTER".

SELECT THE DESIRED TASK FROM THE LIST WITH THE APPROPRIATE SIDE KEY, AND PRESS "ENTER"

(OTHER SIDE)

PRESS THE FOLLOWING KEYS TO GO TO:

1. SETPOINTS
2. TOD SCHEDULES (IF APPLICABLE)
3. RELAY/DIGITAL OUTPUTS
4. DIGITAL INPUTS
5. ANALOG INPUTS
6. ANALOG OUTPUTS
7. ANALOG INPUT ALARMS
8. DIGITAL INPUT ALARMS
9. CLEARS ANY COMPUTER RELAY OVERRIDES WITHIN THAT TASK

**COM-TROL MCS-4000
"HOT KEY" INSTRUCTIONS**

FROM THE "MAIN MENU", PRESS THE SIDE KEY FOR "TASK STATUS", AND PRESS "ENTER".

SELECT THE DESIRED TASK FROM THE LIST WITH THE APPROPRIATE SIDE KEY, AND PRESS "ENTER"

(OTHER SIDE)

PRESS THE FOLLOWING KEYS TO GO TO:

1. SETPOINTS
2. TOD SCHEDULES (IF APPLICABLE)
3. RELAY/DIGITAL OUTPUTS
4. DIGITAL INPUTS
5. ANALOG INPUTS
6. ANALOG OUTPUTS
7. ANALOG INPUT ALARMS
8. DIGITAL INPUT ALARMS
9. CLEARS ANY COMPUTER RELAY OVERRIDES WITHIN THAT TASK

**COM-TROL MCS-4000
"HOT KEY" INSTRUCTIONS**

FROM THE "MAIN MENU", PRESS THE SIDE KEY FOR "TASK STATUS", AND PRESS "ENTER".

SELECT THE DESIRED TASK FROM THE LIST WITH THE APPROPRIATE SIDE KEY, AND PRESS "ENTER"

(OTHER SIDE)

PRESS THE FOLLOWING KEYS TO GO TO:

1. SETPOINTS
2. TOD SCHEDULES (IF APPLICABLE)
3. RELAY/DIGITAL OUTPUTS
4. DIGITAL INPUTS
5. ANALOG INPUTS
6. ANALOG OUTPUTS
7. ANALOG INPUT ALARMS
8. DIGITAL INPUT ALARMS
9. CLEARS ANY COMPUTER RELAY OVERRIDES WITHIN THAT TASK

**COM-TROL MCS-4000
"HOT KEY" INSTRUCTIONS**

FROM THE "MAIN MENU", PRESS THE SIDE KEY FOR "TASK STATUS", AND PRESS "ENTER".

SELECT THE DESIRED TASK FROM THE LIST WITH THE APPROPRIATE SIDE KEY, AND PRESS "ENTER"

(OTHER SIDE)

PRESS THE FOLLOWING KEYS TO GO TO:

1. SETPOINTS
2. TOD SCHEDULES (IF APPLICABLE)
3. RELAY/DIGITAL OUTPUTS
4. DIGITAL INPUTS
5. ANALOG INPUTS
6. ANALOG OUTPUTS
7. ANALOG INPUT ALARMS
8. DIGITAL INPUT ALARMS
9. CLEARS ANY COMPUTER RELAY OVERRIDES WITHIN THAT TASK

**COM-TROL MCS-4000
"HOT KEY" INSTRUCTIONS**

FROM THE "MAIN MENU", PRESS THE SIDE KEY FOR "TASK STATUS", AND PRESS "ENTER".

SELECT THE DESIRED TASK FROM THE LIST WITH THE APPROPRIATE SIDE KEY, AND PRESS "ENTER"

(OTHER SIDE)

PRESS THE FOLLOWING KEYS TO GO TO:

1. SETPOINTS
2. TOD SCHEDULES (IF APPLICABLE)
3. RELAY/DIGITAL OUTPUTS
4. DIGITAL INPUTS
5. ANALOG INPUTS
6. ANALOG OUTPUTS
7. ANALOG INPUT ALARMS
8. DIGITAL INPUT ALARMS
9. CLEARS ANY COMPUTER RELAY OVERRIDES WITHIN THAT TASK